

May 12th, 2021

Boost Control HMI Monitoring Activation Guide

The SpecPAK™ VR Series Constant Pressure System is a multi-pumping system that combines the high technology of VR Series pumps with the versatility of Franklin's control systems.

Step 1:



Turn off the computer.

Step 2:



Go to the settings menu.

Step 3:



Go to the Engineer settings menu.


NEW PRODUCTS LATIN AMERICA

Step 4:




Go to the Monitoring menu.

Step 5:



Activate the monitoring function when choosing the "Used" option.

Step 6:




Modify the ID value in the format:

052 + four last digits of the HMI's serial number (you can find it on the back)


NEW PRODUCTS LATIN AMERICA

Step 7:




Enable the ethernet monitoring function when choosing the "ON" option.

Step 8:



Choose the communication format "NEW FORMAT 2".

Step 9:



Keep the internal communication delay in "3 SEC".

NEW PRODUCTS LATIN AMERICA

Once you have completed the above steps please send the following information to the activacionesboostcontrol@fele.com :

1. End User Name:
2. Installation Site Name:
3. Installation Site Address:
4. End User Email:
5. System ID (Step 6):
6. Desired password: